



PSR Dual Sport Kickstand Installation Instructions 04-04501 / DK2

****Removable Thread Locking Compound is recommended on all bolt threads****

1. Verify bike model & kickstand application before installation!
2. Place bike securely on a center stand recommended.
3. Remove left footpeg and bracket, then remove the footpeg from the bracket.
4. Install PSR kickstand under the included left footpeg bracket using stock bolt on the bottom and the supplied M12x30 bolt on the top. Tighten to factory spec.
5. Reinstall the footpeg to the footpeg bracket.
6. Rotate kickstand through its entire travel and check for clearance prior to use.

Usage & Maintenance of PSR Dual Sport Kickstand:

1. Check all hardware for tightness before each ride.
2. Do Not Start the bike with kickstand down.
3. Do Not Kickstart the bike with kickstand down.
4. Clean and lubricate the kickstand pivot area after each ride.

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. PSR is not responsible for any losses, damages or claims resulting from injuries sustained or alleges to have been sustained by the installation of this product not installed by a certified mechanic experienced in the installation of component parts on motorcycles. PSR is not responsible for the functionality of the product not properly installed or under circumstances in which there has been a modification to the product by any person not employed by PSR.